

ASSEMBLY GUIDE

L SHAPED BASE CORNER - 880/ 900/ 1000MM

REQUIRED TOOLS:

Cross Head Screw Driver
Drill & Drill Bits
Hammer
Spirit Level
PVA Wood Glue
Pliers

REQUIRED COMPONENTS:


12x Wooden Dowels	3x Hanging Brackets
22x Metal Dowels	3x Wall Plates
12x Cams	
7x Shelf Brackets	
10x Round head screws for the back panel	
6x 30mm Screws for the hanging brackets	

WARNING


This product should be assembled by a competent individual and according to the above instructions only. Failure to correctly install the product could result in it being dangerous. Please ensure that all components are included and if not, or if you have any other questions, please contact us by sending an email to; sales@tradekitchensforall.co.uk

This product may contain small parts and solvent, which should be kept out of the way of children at all times. Seek immediate medical attention if any solvent comes into contact with eyes or is swallowed.

1.



Before assembly place on a solid flat surface and make sure that you have all the correct tools.



Insert three metal dowels into the holes provided at either end of the side panel and one in the centre as per top image. Prior to inserting apply a small amount of wood PVA glue in the holes.

2.



Proceed to insert the wooden dowels into the corresponding holes in the base panel. Again prior to inserting applying a small amount of wood PVA glue into the holes.

At this stage be sure that the white edges of the top and bottom panels are facing the front of the cabinet. Then proceed to tighten the cams with a cross head screw driver.

3.




Repeat the above process with one wooden and one metal dowel in each of the top panels, again tightening the cams with a cross head screw driver.

4.



You can now proceed to place the remaining side panel on to complete one half of the L Shaped corner cupboard, using the above method. Be sure to tighten all the cams in place.


5.



Now insert the back board into the grooves of the side panels. Fix into position using the roundhead screws provided, fixing 5 screws evenly spaced along the top and along the bottom of the back board into the top rail and the bottom panel.

Insert screws here

6.



For the remaining half of the corner cuboards, repeat the process above, this time placing the dowels into the groove on one of the side panels as per image.



On the top and bottom edge of the side panel, insert a further two metal dowels into the two outside holes and two wooden dowels into the inner holes. Again when inserting the dowels apply a small amount of PVA glue into the holes.

7.




At this stage be sure that the white edges of the top and bottom panels are facing the front of the cabinet and proceed to tighten the cams with a cross head screw driver.

8.



Once the bottom panel is fixed in position take the remaining side panel and insert into the pre cut groove, making sure again at this stage that the white edge is facing the front of the cabinet. Proceed to tighten the cams with a cross head screw driver.

9.



To finish this stage insert the remaing two top panels onto the corresponding dowels in position on the side panel and fix the remaining side panel using the repeat process.

10.




The larger and small cabinets can now be fixed together. Insert the metal dowels into the holes on the larger cabinet, as shown and insert into the corresponding holes on the smaller of the two cabinets.

Again proceed to tighten the cams with a cross head screw driver.

11.




To assemble the shelves take one large and one small sized shelf piece. Insert two metal dowels into the pre cut holes in the larger of the two shelf pieces.



Connect the two pieces together as per image, finishing by tightening the cams using a cross head screw driver.

12.



Position the shelf brackets into the holes provided at your desired height.

16.



The finished product.